IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING

KEEP AWAY FROM WATER

DANGER - Any appliance is electrically live even when the switch is off. To reduce the risk of death by electric shock:

1. **Always unplug appliance immediately after using.**
2. Do not use while bathing or in a shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into water or other liquid.
5. If an appliance falls into water, unplug it immediately. **Do not reach into the water.**

WARNING - To reduce the risk of burns, electrocution, fire, or injury to persons:

1. This appliance should never be left unattended when plugged in.

2. This appliance should not be used by, on, or near children or individuals with certain disabilities.
3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
4. Do not use an extension cord to operate appliance.

5. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.

6. Keep the cord away from heated surfaces.
7. Do not pull, twist, or wrap line cord around appliance, even during storage.
8. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
9. Never use while sleeping.
10. Never drop or insert any object into any opening.
11. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
12. This straightener is hot when in use. Do not let heated surfaces touch eyes or skin.

13. Do not place the heated straightener directly on any surface or on the appliance power cord while it is hot or plugged in.

14. Before plugging in, read the information about dual voltage contained in the instruction section of this manual.
15. Do not attempt to touch the housing of your appliance near the straightening plates, as it is hot when in use.
16. Do not touch hot surfaces of the appliance. Use the handles or knobs.
17. Do not use with a voltage converter.

SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

This straightening iron is intended for household use. This unit is designed to operate at 120–240 volts AC. Use on Alternating Current (50/60 hertz) only.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

DUAL VOLTAGE

This straightening iron will automatically adjust to the proper voltage. Use an adapter plug with correct configuration, prior to use in outlet.

TO FILL WATER RESERVOIR

WARNING: Never remove when hot. Allow to cool before filling.

Press water reservoir release button to remove reservoir from unit. Open rubber reservoir cap and fill with distilled water. Replace rubber cap and snap back onto unit.

STRAIGHTENING BASICS

Plug the steam straightening iron cord into any household outlet, 120V–240V. Slide switch to ON position. Red LED light will indicate power is on. The iron will heat up very quickly. To turn off, slide to OFF position. Red light will go off. Never leave your steam straightening iron on and unattended.

WARNING: The steam straightening iron's ceramic-coated plates will get very hot within a few seconds and should not be placed in contact with the skin after the straightening iron has been turned on.

Start with a hair section that is 1" wide and no more than 1/2" thick. Open the iron and place a hair section between the two hot plates, close to the scalp. Close plates over hair by firmly squeezing the handles together. While maintaining the tension, slowly pull the unit down along the hair section toward the end of hair. At the end of hair section, release the pressure on the handle and allow the hair to slide out. Repeat process on additional sections of hair until you achieve the hair style you desire. It may be necessary to repeat process on certain areas, depending on the texture of your hair.

Some experience is necessary when learning to use this steam straightening iron. After using the iron several times, you will learn the ideal way to straighten and style your hair easily.

STYLING WITH THE NEW EASY-GLIDE STEAM CERAMIC TECHNOLOGY

The plates of your new steam straightening iron have an easy-glide ceramic surface, the latest in technological advances. The ceramic even heat distribution produces the ultimate in healthy, shiny, silky looking hair. You'll find that hair glides easily over the surface of the plates as you're straightening, and that it is easier to clean styling products residue, etc. off the plates after each use. The ceramic surface also helps smooth down flyaways and frizzies. As you smooth your hair, heat is evenly distributed so that the style you create has a salon-perfect, silky smooth, shiny finish. The conditioning steam infuses moisture into the hair leaving it shiny and healthy looking. Hair also glides right through the plates after it's straightened.

The new steam ceramic technology is a pleasure to work with, makes styling your hair easier and provides professional salon results at home. Your steam straightener also features a removable comb to keep hair taut for smoother results.

GET TO KNOW YOUR CERAMIC STEAM STRAIGHTENING IRON





Designer storage pouch with heat resistant inner lining allows hot steam iron to be stored immediately after use.

MEDIDAS DE SEGURIDAD IMPORTANTES

Siempre que use aparatos eléctricos, especialmente en la presencia de niños, debe tomar precauciones básicas de seguridad, entre las cuales las siguientes:

LEA TODAS LAS INSTRUCCIONES ANTES DE USARLO

MANTÉNGALO ALEJADO DEL AGUA

PELIGRO – Cualquier aparato enchufado permanece bajo tensión, aunque esté apagado. Para reducir el riesgo de muerte o herida por descarga:

1. **Siempre desconecte el aparato inmediatamente después de usarlo.**
2. No lo use en el baño o la ducha.
3. No coloque ni guarde el aparato donde pueda caer o ser empujado a una bañera o un lavabo.
4. No coloque el aparato ni lo deje caer al agua u otro líquido.
5. Si el aparato cayera al agua, desconéctelo inmediatamente. **No toque el agua.**

ADVERTENCIA – Para reducir el riesgo de quemaduras, electrocución, incendio o heridas:

1. Nunca deje el aparato desatendido mientras esté conectado.

2. Este aparato no debería ser utilizado por, sobre o cerca de niños o personas con alguna discapacidad.
3. Use este aparato únicamente con el propósito para el cual fue diseñado y solamente según las instrucciones. Sólo use accesorios recomendados por el fabricante.
4. No utilice una extensión con este aparato.

5. No opere este aparato si el cable o la clavija estuviesen dañados, después de que hubiese funcionado mal o que se hubiese caído o si estuviese dañado. Regréselo a un centro de servicio autorizado para que lo examinen y lo reparen.

6. Mantenga el cable alejado de las superficies calientes.
7. Nunca jale, retuerza o enrolle el cable alrededor del aparato.
8. Nunca bloquee las aberturas de aire ni coloque el aparato sobre una superficie blanda, como una cama o un sofá, donde se puedan obstruir.
9. Nunca utilice el aparato mientras esté dormida/o o adormilada/o.
10. Nunca deje caer ni inserte un objeto en ninguna de las aberturas.
11. No lo utilice en exteriores, ni lo haga funcionar donde se estén usando productos en aerosol (spray) o donde se esté administrando oxígeno.
12. Este aparato se vuelve muy caliente.

superficie mientras esté caliente o conectado. Mantenga el cable alejado de las superficies calientes.

14. Lea la información relativa al doble voltaje que se encuentra a continuación antes de enchufar el aparato.
15. El cuerpo del aparato cerca de las placas se vuelve muy caliente. No lo toque.
16. No toque las partes calientes de este aparato. Use el agarre y los botones o perillas.
17. No haga funcionar este aparato con un convertidor de voltaje.

GUARDE ESTAS INSTRUCCIONES INSTRUCCIONES DE USO

Este aparato fue diseñado para uso doméstico. Úselo solamente con Corriente Alterna de 120–240V (50/60 hertz).

El cable de este aparato está dotado de una clavija polarizada (una pata es más ancha que otra). Como medida de seguridad, se podrá enchufar de una sola manera en el tomacorriente. Si no entrara en el tomacorriente, inviértela. Si aún no entrara completamente, comuníquese con un electricista. No intente ir en contra de esta función de seguridad.

DOBLE VOLTAJE

Este aparato es de doble voltaje. Se adaptará automáticamente al voltaje adecuado. Sin embargo, se deberá utilizar un adaptador de enchufe (no se incluye) para utilizarlo fuera de los Estados Unidos.

FUNDAMENTOS DEL ALISADO

Será necesario experimentar un poco al principio. Con práctica, encontrará la manera perfecta para alisar su cabello fácil y rápidamente.

TECNOLOGÍA CERÁMICA "EASY-GLIDE"

Las placas de su nueva plancha alaciadora están cubiertas de una capa de cerámica increíblemente suave, lo último en tecnología cerámica. La cerámica hace que el cabello se deslice fácilmente entre las placas y ayuda a eliminar la estática y el frizz. Las placas distribuyen el calor en forma pareja, lo cual logra resultados profesionales y deja el cabello suave, sedoso y brillante. Las placas también son muy fáciles de limpiar, ya que la cerámica también es un material antiadherente.

El vapor emitido por las placas acondiciona y mantiene el balance hídrico del cabello, dejándolo brillante y saludable.

Es un placer trabajar con esta nueva tecnología, pues facilita el alisado y logra resultados óptimos.

LLENADO DEL DEPÓSITO

ADVERTENCIA - Nunca saque el depósito mientras esté caliente. Permita que enfríe antes de llenarlo. Oprima el botón de liberación del depósito y retire el depósito de la unidad. Abra el tapón de caucho y llene el depósito con agua. Cierre el tapón y vuelva a instalar el depósito en la unidad.

1. Conecte el aparato al tomacorriente (120-240V) y ponga el botón de encendido/apagado en la posición "ON". El indicador luminoso rojo se iluminará y permanecerá encendido mientras el aparato esté encendido. Para apagar el aparato, ponga el botón de encendido/apagado en la posición "OFF". El indicador luminoso rojo se apagará. Nunca deje el aparato desatendido mientras esté conectado.

ADVERTENCIA: Las placas calentarán en segundos. No permita que hagan contacto con la piel después de encender el aparato.

2. Divida el cabello en secciones de 2 pulgadas de ancho por ½ pulgada de espesura o menos.
3. Coloque la plancha cerca del cuero cabelludo, abra las placas y ponga una sección de cabello entre ellas.
4. Cierre las placas y bale la plancha lentamente hacia las puntas, manteniendo las placas bien cerradas.
5. Abra las placas y aflojе el pelo después de llegar a las puntas. Repita estos pasos hasta alcanzar el estilo deseado. Según la textura de su cabello, puede ser necesario alisar cada sección de cabello varias veces.

FAMILIARÍCESE CON SU PLANCHA ALACIADORA CERÁMICA CON VAPOR


Pleno extraíble
Depósito de agua extraíble con apoyapulgar
Placas de 19 mm cubiertas de cerámica
Botón de liberación del depósito
Botón de encendido/ apagado
Doble voltaje

Estuche a prueba de calor que permite guardar el aparato inmediatamente después de usarlo.

USER MAINTENANCE

Your straightening iron is virtually maintenance-free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow to cool and wipe exterior with a cloth. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CAUTION

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then store out of reach of children in a safe, dry location. Do not jerk or strain cord at plug connections.

WARNING:
IF YOU THINK THE POWER IS OFF WHEN THE SWITCH IS OFF, YOU'RE WRONG.

KEEP AWAY FROM WATER



Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

ALWAYS UNPLUG SMALL APPLIANCES

LIMITED TWO-YEAR WARRANTY

Conair will repair or replace, at our option, your appliance free of charge for 24 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center nearest you, together with your sales slip and $5.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a receipt, the warranty period shall be 24 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 24-MONTH DURATION OF THIS WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

MANUFACTURING QUALITY HAIR CARE PRODUCTS WITH PROFESSIONAL HERITAGE AND EXPERTISE FOR 50 YEARS.

SERVICE CENTER
CONAIR CORPORATION
Service Department
150 Milford Road
East Windsor, NJ 08520

©2009 CONAIR CORPORATION
www.conair.com
09NP12927

IB-9201

miniPRO®
¾" STEAM STRAIGHTENER



For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

CONAIR®

Instruction & Styling Guide

Model SS2

INSTRUCCIONES DE MANTENIMIENTO

Su aparato casi no necesita mantenimiento. No necesita lubricación. Mantenga todas las aberturas libres de polvos y pelusas. Cuando sea necesario limpiarlo, desenchúfelo, permita que entrie y limpie la superficie exterior con un paño húmedo. En caso de mal funcionamiento, desconecte el aparato, permita que enfrie y regréselo a un centro de servicio autorizado. No intente reparar el aparato.

PRECAUCIÓN

NUNCA jale, tuerza ni retuerza el cable eléctrico. Nunca lo enrolle con fuerza alrededor del aparato. Esto podría dañar la junta flexible que lo conecta, produciendo su ruptura o un cortocircuito. Inspeccione el cable con frecuencia para asegurarse que no esté dañado. Deje de usar el aparato inmediatamente si el cable parecciera dañado, si el aparato dejara de funcionar o funcionara de manera intermitente.

ALMACENAJE

Cuando no lo utiliza, su aparato es fácil de almacenar. Permita que enfrie y guárdelo en un lugar seco y seguro, fuera del alcance de los niños. No tironee ni retuerza el cable al nivel del enchufe y no enrolle el cable alrededor del aparato. Permita que el cable cuelgue o que la junta que lo conecta al aparato este suelta y recta.

ADVERTENCIA: SI CREE QUE NO HAY CORRIENTE CUANDO EL APARATO ESTÁ APAGADO, ESTÁ EQUIVOCADO

MANTÉNGALO ALEJADO DEL AGUA



Todos sabemos que no se debe mezclar la electricidad y el agua. Pero ¿Sabe usted que un aparato eléctrico permanece bajo tensión aunque esté apagado? Si está conectado, hay corriente. Por lo tanto, siempre desenchufe sus aparatos eléctricos después de usarlos.

SIEMPRE DESENCHUFE LOS APARATOS PEQUEÑOS

GARANTÍA LIMITADA DE DOS AÑOS

Conair reparará o remplazará (a su opción) su aparato sin cargo por un período de 24 meses a partir de la fecha de compra si presentara defectos de materiales o fabricación.

Para obtener servicio técnico bajo esta garantía, regrese su aparato al Centro de Servicio indicado a continuación, junto con su recibo de compra y un cheque o giro postal de $5.00US por gastos de manejo y envío. Los residentes de California sólo necesitan dar una prueba de compra y deben llamar al 1-800-3-CONAIR para recibir instrucciones de envío. En ausencia del recibo de compra, el período de garantía será de 24 meses a partir de la fecha de fabricación.

CUALQUIERA GARANTÍA, OBLIGACIÓN O RESPONSABILIDAD IMPLÍCITAS, INCLUYENDO PERO NO LIMITADAS A LA GARANTÍA IMPLÍCITA DE COMERCIABILIDAD Y APTITUD PARA UN PROPÓSITO ESPECÍFICO, ESTARÁN LIMITADAS POR LOS 24 MESES DE LA PRESENTE GARANTÍA ESCRITA. Algunos Estados no permiten limitaciones sobre la duración de una garantía implícita, de modo que las limitaciones mencionadas pueden no regir para usted.

CONAIR NO SERÁ RESPONSABLE EN NINGÚN CASO POR ALGÚN DAÑO ESPECIAL, INCIDENTAL O CONSECUENTE DEBIDO AL INCUMPLIMIENTO DE ESTA O CUALQUIER OTRA GARANTÍA, EXPRESA O IMPLÍCITA. Algunos Estados no permiten la exclusión o limitación de daños especiales, incidentales o consecuentes, de modo que las limitaciones mencionadas pueden no regir para usted.

Esta garantía le otorga derechos legales específicos y usted puede tener otros derechos que varían de un Estado a otro.

CENTRO DE SERVICIO

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307

©2009 CONAIR CORPORATION
www.conair.com
09NP12927

IB-9201

AYUDÁNDOLE A CUIDAR SU CABELLO CON PRODUCTOS DE CALIDAD, FABRICADOS CON COMPETENCIA PROFESIONAL DESDE HACE 50 AÑOS.

miniPRO®
ALACIADORA CON VAPOR 19 MM

Para su seguridad y para disfrutar plenamente de este producto, siempre lea las instrucciones cuidadosamente antes de usarlo.

CONAIR®

Instrucciones

Modelo SS2